

SALON SELECT PRO CONDITIONER w/ MICROSIL[®] FINISH

FORMULATION:

		<u>% WT.</u>
A1	Dionized Water	Q.S.
A2	Propyl Paraben	0.10
A3	Methyl Paraben	0.20
A4	MICROSIL[®] FINISH CHEMSIL SILICONES, INC.	10.0
	<i>Water (and) Amodimethicone (and) Cetrimonium Bromide (and) Propoxytetramethyl Piperdiny Dimethicone (and) Cetrimonium Chloride (and) Trideceth-12 (and) Trideceth-6 (and) C11-15 Pareth 7</i>	
A5	Propylene Glycol	3.0
B1	Cetyl Alcohol	3.00
B2	Stearyl Alcohol	2.00
B3	Cutina EGDS Cognis <i>Glycol Distearate</i>	0.80
C1	Cranberry Fragrance Ascent Aromatics	0.30
C2	Hydantol 55 KCI <i>DMDM Hydantoin</i>	0.40

PROCEDURE:

1. Heat while adding ingredients A1-A5 to 80C under strong agitation.
2. Add B1-B3 while mixing. Mix for 15 minutes or until all solids are melted and system is homogenous. Turn off heat and maintain good agitation as product cools without incorporating air.
3. At 45 C add C1 and C2 to batch and stop mixing at 40C

SPECIFICATIONS:

Appearance – Viscous white emulsion

pH – 6.5

Stability – 40c eight weeks, pass 3 F/T

Product Code: CRL-10-42B3

04.2011

STATEMENTS AND METHODS PRESENTED ARE BASED UPON THE BEST AVAILABLE INFORMATION AND PRACTICES KNOWN TO CHEMSIL SILICONES, INC. AT PRESENT, BUT ARE NOT REPRESENTATIONS OR WARRANTIES OF PERFORMANCE, RESULT OR COMPREHENSIVENESS, NOR DO THEY IMPLY ANY RECOMMENDATIONS TO INFRINGE ANY PATENT OR AN OFFER OF LICENSE UNDER ANY PATENT.

We Provide **YOUR** Silicone Solutions TM