

Clear Leave On Spray Conditioner w/*Microsil*® Finish 5%

<u>FORMULATION:</u>		<u>% WT.</u>
A1.	Deionized Water	93.85
A2.	Microsil® Finish CHEMSiL SILICONES INC. <i>Propoxytetramethyl Piperdiny Dimethicone (and) Cetrimonium Chloride (and) Cetrimonium Bromide (and) Trideceth-6 (and) C11-C15 Pareth-7</i>	5.00
A3.	Licoside K Lincoln Fine	0.40
B1.	Polysorbate-20 <i>Ammonium Cocoyl Isethionate</i>	0.60
B2.	Fragrance	0.15
C3.	Licoside K Lincoln Fine <i>Methylchloroisothiazolinone (and) Methylisothiazolinone</i>	0.08

PROCEDURE:

Step 1: Add in order and mix for 15 minutes.

Step 2: Combine Fragrance & Polysorbate-20 and mix until uniform. Add to batch and mix for 10 minutes.

SPECIFICATIONS:

pH – 4.23

Specific Gravity – 0.999

CRL-11-30B

01.2012

STATEMENTS AND METHODS PRESENTED ARE BASED UPON THE BEST AVAILABLE INFORMATION AND PRACTICES KNOWN TO CHEMSIL SILICONES, INC. AT PRESENT, BUT ARE NOT REPRESENTATIONS OR WARRANTIES OF PERFORMANCE, RESULT OR COMPREHENSIVENESS. NOR DO THEY IMPLY ANY RECOMMENDATIONS TO INFRINGE ANY PATENT OR AN OFFER OF LICENSE UNDER ANY PATENT.

We Provide **YOUR** Silicone Solutions™